


Cowl Panel

Removal

1. Refer to: [Cowl Panel Grille](#) (501-02 Front End Body Panels, Removal and Installation).
2. On both sides.
Refer to: [Headlamp Assembly](#) (417-01 Exterior Lighting, Removal and Installation).
- 3.



Installation

1. To install, reverse the removal procedure.