


## Windshield Wiper Pivot Arm

### Removal


**NOTE:** *LH side shown, RH side similar.*

**NOTE:** *Removal steps in this procedure may contain installation details.*

1. Torque : 24 Nm



2. General Equipment : Two Leg Puller




### Installation

1. **NOTE:** *Make sure that the windshield wipers are in the PARK position.*

**NOTE:** *During installation align the wiper pivot arms with the marks on the windshield.*

To install, reverse the removal procedure.



Copyright © Ford Motor Company